

BAFFLE INSTALLATION INSTRUCTIONS:

1. INSTALL BOTH INTAKE AND EXHAUST SIDES OF BAFFLE ON FRONT POSTS OF ENCLOSURE
2. BOTH BAFFLES MUST BE ALIGNED VERTICALLY AT THE SAME RU PLACEMENT OF EQUIPMENT
 - THE **LEFT** SIDE BAFFLE IS THE **EXHAUST** SIDE (CLOSED FACE TOWARD THE FRONT OF ENCLOSURE)
 - THE **RIGHT** SIDE BAFFLE IS THE **INTAKE** SIDE (CLOSED FACE TOWARD THE REAR OF ENCLOSURE)

4. A: ADJUSTABLE REAR COVER, INTAKE ASSEMBLY
 - PRIOR TO INSTALLING INTAKE BAFFLE INTO RACK, INSTALL ADJUSTABLE REAR COVER **LOOSELY** OVER STUDS ON INSIDE OF INTAKE MAIN BAFFLE BODY
 - INSTALL BRUSH ONTO ADJUSTABLE REAR COVER

** NOTE: IF DESIRED MOUNTING RU LIES WITHIN THE 23rd RU (FROM BOTTOM) THE BRUSH MAY NEED TO BE NOTCHED TO ACCOUNT FOR MIDDLE RAIL SUPPORT HORIZONTAL. TRIM AS NECESSARY.

EXHAUST BAFFLE, LEFT SIDE:
BAFFLE ORIENTED WITH CLOSED FACE TOWARD FRONT OF ENCLOSURE

3. EXHAUST BAFFLE (LEFT SIDE):

- A. SLIDE EXHAUST BAFFLE ASSEMBLY INTO ENCLOSURE AT DESIRED RU TO THE LEFT OF YOUR SWITCH
- B. USE QTY. 2 PLASTIC RIVETS TO ATTACH THE **CLOSED** FACE OF THE BAFFLE TO THE **FRONT, OUTSIDE** OF THE FRONT VERTICAL POST

RIGHT SIDE INTAKE BAFFLE INSIDE VIEW

INTAKE BAFFLE, RIGHT SIDE:
BAFFLE ORIENTED WITH CLOSED FACE TOWARD REAR OF ENCLOSURE

4. INTAKE BAFFLE (RIGHT SIDE):

- A. SEE 4,A : ADJUSTABLE REAR COVER INSTALL, ABOVE
- B. SLIDE INTAKE BAFFLE ASSEMBLY INTO ENCLOSURE AT DESIRED RU TO THE RIGHT OF YOUR SWITCH
- C. USE QTY. 4 PLASTIC RIVETS TO ATTACH THE **OPEN** SIDE OF BAFFLE TO THE **FRONT** AND **SIDE** OF THE FRONT VERTICAL POST
- D. AFTER BAFFLE IS SECURED IN CORRECT LOCATON, REACH INTO INTAKE OF BAFFLE FROM FRONT AND SLIDE ADJUSTABLE REAR COVER TO BACK ACCOMDATE FOR THE DEPTH OF YOUR SPECIFIC SWITCH
- E. TIGHTEN BOTH WING NUTS TO SECURE ADJUSTABLE REAR COVER

5. INSTALL TOP /BOTTOM COVERS ON BOTH SIDES:

- A. ALIGN TOP/BOTTOM COVER SECTION BEHIND FRONT POSTS AND USE 3 PLASTIC RIVETS TO ATTACH
 - INSTALL QTY. 1 PLASTIC RIVET INSIDE BAFFLE TO SIDE OF VERTICAL POST
 - INSTALL QTY. 2 PLASTIC RIVETS PER SECTION INTO COVER AND BAFFLE INSIDE OF BAFFLE
- B. WHEN INSTALLING, NOTE REMOVEABLE NOTCHES REAR OF COVERS. COVERS MAY NEED TO BE NOTCHED TO ACCOMDATE FOR YOUR SPECIFIC REAR RAIL PLACEMENT
- C. REPEAT STEP A IN ON THE TOP AND BOTTOM, FOR BOTH INTAKE AND EXHAUST BAFFLES

** NOTE: IF DESIRED RU IS WITHIN THE BOTTOM 3 RU OF THE ENCLOSURE, BOTTOM COVERS MAY NEED TO BE RESTING IN LOCATION PRIOR TO MAIN INTAKE/ EXHAUST BAFFLE BEING INSTALLED

- SWITCH AND ENCLOSURE SHOWN FOR REFERENCE ONLY -

INTERPRET DRAWING PER ASME Y14.5M-1994
DIMENSIONAL LIMITS APPLY AFTER APPLICATION OF FINISH
DRAWING NOT TO SCALE
TOLERANCE UNLESS OTHERWISE NOTED:
ANGULAR +/- 1°
.XXXX +/- .010
.XXX +/- .015
.XX +/- .030
.X FOR REF. ONLY

NOTICE:

Use of this document is subject to a confidentiality and nondisclosure agreement with Great Lakes Case & Cabinet Co., Inc. (GLCC) and may not be reproduced, disclosed or utilized in whole or in part without prior written authorization from GLCC.

PART NUMBER: **ENSAB14AX100**
QTY PER UNIT: 1
MATERIAL TYPE:
MATERIAL GAUGE:
FINISH:
DRAWN CD DATE 12/14/2010
CHECKED & APP. WSS DATE 12/17/12

TITLE **14 RMU EN INTAKE / EXHAUST BAFFLE FOR 7009 CISCO SWITCH**
GREAT LAKES CASE & CABINET CO., INC.
P.O. BOX 551 EDINBORO, PA 16412
PHONE (814) 734-7303 FAX (814) 734-3907
E-MAIL glcc@greatcabinets.com

THIRD ANGLE PROJECTION

UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES

DWG NO: **1018038** REV **1** SHEET: 3 OF 1